



Nex Elite

User Manual

Thank you for choosing Nex Products!

Picture a flexible vaping experience in your head, add to it the style you need and the comfort of a closed system: you are looking at a Nex Premium device. The Premium is here to make your choice easy, don't confine yourself, leave compromises to the undecided and get with the closed system of the future. Direct to lung and Mouth to lung at a switch's notice with many juice options and a highly performant internal battery is only the beginning.

Please read this manual carefully to ensure proper use. For additional information or questions regarding to this product or its use, please visit www.revenantvape.com

Features:

- Flexible and easy to use Closed System Vaping
- Closed system product with open system experience
- Switch between MTL and DTL Settings
- Adjustable Airflow
- Ceramic Coil Inside

Specification:

Size: 90.9x48.6x22.2mm

Battery Cell: Lithium, 1400 mAh Built In



How To Use:

Power on/off: Press the fire button 5 times in quick succession to turn on/off the device.

How to replace cartridge: Simply remove the mouth piece and pull the cartridge out. Replace with a new one (sold separately).

Note: there is a cartridge adapter between 10ml cartridge and 2ml cartridge included in the device.

How to switch between DLT/MTL: Easy switch between DTL and MTL by pressing the switch button on the top and replacing the cartridge (sold separately) suitable.

How to adjust the airflow: simply by rotating the airflow ring on the bottom of the device to increase or decrease the airflow

Charging: Plug in the Micro USB cable to charge the battery.

Function:

Short Circuit Protection:

1. When the short circuit occurs before working, the button light flashes for 5 times and there will be no output power.

2. Low Wattage Protection

When the battery voltage is lower than 3V, the fire button light flashes for 3 times and the battery will be locked.

3. Over Vaping Protection

When the fire button is pressed for more than 10 seconds, the light flashes 3 times then goes off. The battery will be locked.

4. Low Battery Protection

When the battery is less than 10%, the light will flash till it goes off completely

Caution:

1. It is intended for usage by people over 18, NOT by non-smokers, children, pregnant or breastfeeding women, people with or at risk of heart disease, or people taking medication for depression or asthma. The electronic cigarette is not a smoking cessation device.

2. Replace the cartridge before the cartridge becomes completely empty in order to avoid dry burnt or damage to the device.

3. Please keep this unit out of reach of children or pets.

4. Do not place it in extremely temperatures.

5. Do not try to disassemble the battery.

6. This device does not mean to be used as a nicotine replacement therapy for smoking cessation